




ABSPMS-40L

SPARE PARTS FOR ABSPMS-40L

<u>Part Number</u>	<u>DESCRIPTION</u>
01	BIG BELT PULLEY
02	BELT 425PJ12
03	BEARING 6006
04	BELT 390PJ12
05	RING GEAR
06	BEARING 305-6307
07	BEARING 305-6208
08	PINION
09	BEARING 305-6205
10	BEARING 6006
11	GEAR SHAFT
12	BEATER
13	PIVOT BRACKET
14	LEVER SHAFT